



PLUS 100 PAN CONTROL SYSTEM FOR DOUGH-RETARDES



**MANUALE D'USO E MANUTENZIONE
USE AND MAINTENANCE MANUAL**

CONTENTS

INTRODUCTION

Page 4	1.1	General
Page 4	1.2	Product ID codes
Page 5	1.3	Overall dimensions
Page 5	1.4	Identification data

CHAP. 1

INSTALLATION

Page 6	2.1	Important information for installer
Page 6	2.2	Standard assembly and use kit

CHAP. 2

FUNCTIONS

Page 7	3.1	Functions managed by the PLUS 100 PAN
--------	-----	---------------------------------------

CHAP. 3

TECHNICAL CHARACTERISTICS

Page 8	4.1.	Technical characteristics
Page 9	4.2	Warranty terms

CHAP. 4

PARAMETER PROGRAMMING

Page 10	5.1	Control panel
Page 11	5.2	LCD display
Page 12	5.3	General features
Page 12	5.4	Key to symbols
Page 12	5.5	Setting and displaying the set-points
Page 13	5.6	Level 1 programming
Page 14	5.7	List of Level 1 variables
Page 15	5.8	Level 2 programming
Page 16	5.9	List of Level 2 variables

CHAP. 5

USING THE UNIT

Page 18	6.1	Cold/hot: maintaining room temperature
Page 18	6.2	Humidifying/dehumidifying: maintaining room humidity
Page 19	6.3	Ventilation
Page 19	6.4	Air changeover
Page 19	6.5	Clock / calendar
Page 20	6.6	Manual cycles
Page 21	6.7	Automatic cycles
Page 25	6.8	Telewin

CHAP. 6

TROUBLESHOOTING

Page 26	7.1	Alarms: description and procedures
Page 27	7.2	Troubleshooting guide

CHAP. 7

ALLEGATI / APPENDICES

Page 29	A.1	EC declaration of conformity
Page 30	A.2	PLUS 100 PAN connections diagram

CHAPTER 1: INTRODUCTION

1.1**GENERAL**


The PLUS 100 PAN system allows the user to control temperature and humidity. The system consists of the 100 MASTER unit, on which all the electrical connections are made, and the PLUS 100 PAN control panel, which features a large LCD display to provide rapidly available, complete information on room status. The system allows the user to cool, heat and ventilate the room, switch the room light on/off, humidify it, effect an air changeover, dehumidify it, defrost it and control alarms.

1.2**PRODUCT ID CODES**

**PLUS100 PAN control of temperature and humidity for
pause-leavening applications.**

OVERALL DIMENSIONS

1.3



IDENTIFICATION DATA

1.4

The unit described in this manual has, on its side, an ID plate showing all the relevant identification data:

- Name of Manufacturer
- Code and model of electrical board
- Serial number
- IP protection rating
- Power supply voltage



CHAPTER 2: INSTALLATION

2.1

IMPORTANT INFORMATION FOR THE INSTALLER

1. Install the device in places where the protection rating is observed and try not to damage the box when drilling holes for wire/pipe seats.
2. Do not use multi-polar cables in which there are wires connected to inductive/power loads or signalling wires (e.g. probes/sensors and digital inputs).
3. Do not fit power supply wiring and signal wiring (probes/sensors and digital inputs) in the same raceways or ducts.
4. Minimise the length of connector wires so that wiring does not twist into a spiral shape as this could have negative effects on the electronics.
5. Fit a general protection fuse upstream from the electronic controller.
6. All wiring must be of a cross-section suitable for relevant power levels.
7. When it is necessary to make a probe/sensor extension, the wires must be of the correct cross-section, which in any case must be at least 1 mm².

2.2

STANDARD ASSEMBLY AND USE KIT

The **PLUS 100 PAN** system is supplied with the following assembly and utilisation items:

n°2 temperature sensors
n°1 fixing bracket
n°1 telephone plug lead
n°1 user's manual

CHAPTER 3: FUNCTIONS

3.1

FUNCTIONS CONTROLLED BY THE PLUS 100 PAN

Display and adjustment of temperature and humidity settings (neutral zone).

- Activation/deactivation of stand-by mode.
- Sensor alarm/warning signals.
- Adjustment of differential temperature and humidity parameters.
- Adjustment of air changeover control parameters.
- Adjustment of defrosting parameters.
- Adjustment of fan parameters.
- Display of output status.
- Simultaneous display of temperature and humidity values.
- Automatic program management with automatic variation of temperature and humidity settings over time.
- Clock function

CHAPTER 4: TECHNICAL CHARACTERISTICS

TECHNICAL CHARACTERISTICS

4.1

Power supply		
Voltage	230 V~ ± 10% 50 Hz	
MAX power absorption	~ 8 VA	
Climatic conditions		
Working temperature	-10 - 60°C	
Storage temperature	-30 - 70°C	
Relative humidity	below 90% RH	
Input characteristics		
Analogical inputs	NTC 10K 1%	Temperature sensor
	4...20 mA	Humidity sensor
Read resolution	1°C	Temperature
	1 RH%	Humidity
Sensor read precision	± 0.5 °C see characteristics of humidity sensor	
Read range	-45...+45 °C	
	0...99 RH%	
Output characteristics		
Outputs on relay	1 output on terminal N.A. 30A (AC1) 230 V AC 9 outputs on terminal N.A. 16A (AC1) 230 V AC	
Dimensional characteristics		
100 MASTER box dimensions (mm)	114 x 69 x 214	(HxDxL)
PLUS PAN keypad box (mm)	98 x 180 x 35	(HxDxL)
Insulation characteristics		
Keypad protection rating	IP55	

PLUS 100 electronic controllers are covered by a 24-month warranty against all manufacturing defects, valid from date of delivery. If the system malfunctions as a result of tampering, impact or improper installation the warranty will automatically be rendered null and void. It is strongly recommended that you observe all instructions/information regarding the technical characteristics of the device.

**WARNING !**

Any modifications made to wiring and/or internal components or any tasks carried out in a way that fails to comply with the information/instructions in this manual shall not only render the warranty null and void immediately but may also lead to malfunctions, irreparable damage, serious injury or put persons/objects in danger.




PEGO S.r.l. declines any responsibility for possible errors or inaccuracies written in this manual as a result of printing or transcription errors.

PEGO S.r.l. reserves the right to modify its products as it deems necessary without altering its main characteristics. Each new release of a PEGO user manual replaces previous ones.

CHAPTER 5: PARAMETER PROGRAMMING

CONTROL PANEL


5.1



1. LCD display
2. Automatic cycle progress bar.
3. Cycle START/STOP (hold for a few seconds to start or stop an automatic cycle) / Timer (press once to show day and time of end of cycle in progress).
4. UP (**Automatic cycle programming**).
5. Stand-by (system at standstill, does not interrupt cycle in progress).
6. SET temperature / SET humidity (press successively to alternate temperature and humidity).
7. DOWN, **forced defrosting**, alarm mute.
8. Room light.

5.2

LCD DISPLAY



1. Progress of PHASE 1 (**cooling** duration set by final user, physically occupies sectors n° 1, 2, 3, 4, 5).
2. Progress of PHASE 2 (**maintenance**, so-called elastic phase, physically occupies sectors n° 6, 7, 8, 9, 10).
3. Progress of PHASE 3 (**leavening**, duration set by final user, physically occupies sectors n° 11, 12, 13, 14, 15, 16)
4. Progress of PHASE 4 (**product ready settling**, max. duration 4 hours, occupies the last sectors n° 17, 18, 19, 20).
5. Relative ambient humidity / parameter values / error codes.
6. Ambient temperature / parameter values.
7. Programming (controller is in programming mode).
8. Cooling (flashes if called for dehumidification only).
9. Heating (flashes if called for dehumidification only).

10. Humidification.
11. Dehumidification.
12. Defrosting.
13. Evaporator fans (both high and low speed).
14. Light.
15. Alarm.
16. Stand-by (light on continuously - controller ON, light flashing, controller in STAND-BY).
17. Time / date / time parameter values.

5.3**GENERAL**

To enhance safety and simplify the operator's work, the **PLUS 100 PAN system** has two programming levels; the first level (Level 1) is used to configure the frequently-modified SET-POINT parameters. The second programming level (Level 2) is for general parameter programming of the various controller work modes.

It is not possible to access Level 2 programming directly from Level 1: you must exit the programming mode first.

5.4**KEY TO SYMBOLS**

For purposes of practicality the following symbols are used:

- (▲) the UP key is used to increase values and in **programming the cycles**;
- (▼) the DOWN key is used to decrease values and mute the alarm.

5.5**SETTING AND DISPLAYING THE SET-POINTS**

1. Press the **SET key** to display the current **SET-POINT** (temperature or humidity).
2. Hold down the **SET key** and press the (▲) or (▼) keys to modify the **SET-POINT**.
3. Release the **SET key** to return to room temperature display: the new setting will be saved automatically..

To gain access to the Level 1 configuration menu proceed as follows:

1. Press the (▲) and (▼) keys simultaneously and keep them pressed for a few seconds until the first programming variable appears on the display.
2. Release the (▲) and (▼) keys.
3. Select the variable to be modified using the (▲) or (▼) key.
4. When the variable has been selected it is possible:
 - Display the setting in the respective sector of the display (5 or 17 page 11)
 - to modify the setting by pressing the SET key and the (▲) or (▼) keys.

When configuration values have been set you can exit the menu by pressing the (▲) and (▼) keys simultaneously for a few seconds until the room temperature reappears; alternatively, do not press any key for a few seconds.

5. The new settings are saved automatically when you exit the configuration menu.

5.7

LIST OF LEVEL 1 VARIABLES (User level)

LABEL	MEANING	RANGE	DEFAULT	VALUE
d-t	Temperature difference compared to main SET-POINT	1-10 °C	2	
d-U	Differential for Humidification compared to main SET-POINT	1-10 RH%	5	5
d-d	Differential for Dehumidification compared to main SET-POINT	1-10 RH%	5	5
d0	Air changeover interval (parameter only active during the leavening phases)	00...24 hours	0:00	
d1	Air changeover duration (parameter only active during the leavening phases)	1....60 min'	6 min	
d4	Defrosting interval, interval between one defrosting and the next d4=0 no defrosting. (parameter only active during cooling and maintenance stages)	0..24 hours	8	
d5	Max defrost duration time	1..60 min'	20	
d6	End of defrosting temperature SET-POINT. Defrosting is not executed if the temperature read by the defrosting sensor is higher than the end of defrosting setting. (in the event of a faulty sensor defrosting is timed)	-35 - 45 °C	12°C	
F5	Fan stop time (Expressed in minutes) At the end of defrosting the fans can be kept at standstill for a further set time. This time begins at the end of defrosting (parameter active only in the cooling and maintenance phases)	0 - 10 min'	2 min	
F6	Fan shutdown temperature. (Expressed in °C.) At the end of defrosting or at start-up the fans can be kept at standstill until the evaporator sensor temperature setting is reached. (parameter active only in the cooling and maintenance phases) *	-20 - 30 °C.	23 °C.	
tEu	Defrosting sensor temperature display (evaporator)	--	Read only	
DMy	Current date	dd:mm:yy		
HMS	Current time	0:00 .. 23:59 hh:mm		

To access the second programming level press the UP (▲) and DOWN (▼) keys and the LIGHT key simultaneously for a few seconds.

When the first programming variable appears the system automatically goes to stand-by.

1. Select the variable to be modified by pressing the UP (▲) and DOWN (▼) keys.

When the parameter has been selected it is possible to:

2. View the setting in the respective sector of the display (5 or 17, page 11).

3. Modify the setting by holding the SET key down and pressing the (▲) or (▼) key.

4. When configuration settings have been completed you can exit the menu by pressing the (▲) and (▼) keys simultaneously and keeping them pressed until the room temperature value reappears.

Exit from Level 2 is not automatic, even if keys are left untouched for a long time.

5. Changes are saved automatically when you exit the configuration menu.

6. To enable the electronic controller press the STAND-BY key.

5.9

LIST OF LEVEL 2 VARIABLES (Installer level)

LABEL	MEANING	RANGE	DEFAULT	VALUE
AC	Door switch input status	0= NO 1= NC	0	
C1	Minimum time between compressor shutdown and subsequent switching on	0...15 min'	0	
Ad	Network address for connection to the TeleWIN PRO system	0-31	0	
dEU	Dehumidification mode select. Separate dehumidification calls heat/cold by temperature only	0= cooling 1=heating 2= separated dehumid.	2	
EnU	Humidification enable	1= enabled 0= disabled Humidification control only executed during leavening and settling phases.	1	
End	Dehumidification enable	1= enabled 0= disabled Humidification control only executed during leavening and settling phases.	1	
CAt	Ambient sensor value correction	-10...+10	0	
CAU	Humidity sensor value correction	-20...+20	0	
St1	First leavening step temperature set-point	0...+45 °C.	5 °C.	
SU1	First leavening step humidity set-point	50...99 rH% (50%=humidity not controlled)	85%	
t1	First leavening step duration hh:mm	00:00...2:00 hh:mm	00:30	
St2	Second leavening step temperature set-point	0...+45 °C.	10 °C.	
SU2	Second leavening step humidity set-point	50...90 rH% (50%= humidity not controlled)	80%	
t2	Second leavening step duration hh:mm	00:00...2:00 hh:mm	00:30	
St3	Third leavening step temperature set-point	0...+45 °C.	16 °C.	
SU3	Third leavening step humidity set-point	50...99 rH% (50%= humidity not controlled)	80%	

t3	Third leavening step duration hh:mm	00:00...2:00 hh:mm	00:30	
St4	Fourth leavening step temperature set-point	0...+45 °C.	16 °C.	
SU4	Fourth leavening step humidity set-point	50...99 rH% (50%= humidity not controlled)	80%	
t4	Fourth leavening step duration hh:mm	00:00...2:00 hh:mm	00:00	
St5	Fifth leavening step temperature set-point	0...+45 °C.	16 °C.	
SU5	Fifth leavening step humidity set- point	50...90 rH% (50%= humidity not controlled)	80%	
t5	Fifth leavening step duration hh:mm	00:00...2:00 hh:mm	00:00	
Hr	Humidity control	Hr = 1 humidity control enabled Hr= 0 humidity control disabled. Humidity sensor can be disconnected without error, the display shows evaporator sensor instead of humidity (if dE=0)	1	
dE	Evaporator sensor exclusion	0 = sensor present 1 = sensor absent	0	
EnC	Enables cold (cooling) during manual, automatic leavening and settling.	0 = cold disabled 1 = cold enabled	1	
Str	Settling phase temperature set- point	0...+45 °C.	12	
SUr	Settling phase humidity set-point	50...99 rH%	80	
d9	Defrost enable during cooling	0 = defrosting disabled 1 = defrosting enabled	0	

CHAPTER 6: USING THE UNIT

6.1

COLD/HEAT: MAINTAINING AMBIENT TEMPERATURE

Heating/cooling is neutral-zone controlled on the basis of the temperature set-point (key 6) and the temperature differential (parameter d-t).

Cooling is activated when the set + differential threshold is passed and stays on until the set-point is reached.

Heating is activated when the setting – differential threshold is reached and stays on until the set-point is reached.

6.2

HUMIDIFICATION/DEHUMID.: MAINTAINING AMBIENT HUMIDITY

Humidity and dehumidification are neutral-zone controlled during the leavening, maintenance and settling phases only, and only if the programmed set-point is greater than the settable minimum ***(50%)** on the basis of the humidity set-point (key 6) and the differential for Humidification (parameter d-U) and differential for Dehumidification (parameter d-d).

Humidification is activated below the **set – differential for Humidification (parameter d-U)** threshold and stays on until the set-point is reached.

Dehumidification is activated above the **set + differential for Dehumidification (parameter d-d)** threshold and stays on until the set-point is reached.

Humidity control can be disabled via the Hr (relative humidity) parameter, or by setting the set point to the minimum R.H.% 50 = humidity control disabled (display only).

Dehumidification alone be disabled via the End parameter.

Humidification alone can be disabled via the EnU parameter.

There are three dehumidification modes (dEU parameter):

1. Dehumidification with cooling (cold is called to dehumidify, heat is added only to maintain ambient temperature).
2. Dehumidification with heating (heat is called to dehumidify, cold is added only to maintain ambient temperature).

If the difference in temperature is, with respect to the setting, greater than 5°C (during dehumidification with the compressor and elements) 5°C, the unit with the

greater value shuts down to prevent any overheating or over-cooling which could damage the product.

3. Separated dehumidification (dehumidification output activated only but without cold/heat call).

(*) if the humidity set point is set to the minimum (50%) neither dehumidification nor humidification are controlled

VENTILATION

6.3

Fan speed is regulated by two digital outputs (high/low speed) and run at high speed with the cold call during the cooling and maintenance phases and continuously at low speed during the leavening and settling phases.

Fans are always off during defrosting.

Variants can be controlled via parameters F5 and F6.

AIR CHANGEOVER

6.4

Air changeover is controlled via parameters d0 and d1.

Use d0 to establish the interval between one air changeover and another: the counter starts its count from zero at the start of every manual or automatic leavening cycle. If d0 = 00 no air changeover is carried out.

Use d1 to establish the duration of the air changeover

Cooling, heating, humidification and dehumidification are not activated during air changeover.

CLOCK / CALENDAR

6.5

Current time and date can be adjusted via the dMY and HMS parameters.

The current time is shown on the LCD display.

The controller recognises the manual cycles (only hot or only cold) from the temperature setting only when in stop mode, not in stand-by.

If the set-point is less than or equal to 10°C the controller recognises the manual cold cycle. It will consequently run the fans simultaneously with the compressor call and execute the programmed defrosts as per the parameter settings; humidity control will not be executed.

If the set-point is higher than 10°C the controller recognises the manual hot cycle. Consequently the fans are run continuously, humidity is controlled according to the RH% setting and the defrost cycles are not executed.

It is possible to set four automatic pause-leavening cycles each with fully independent automatic programmed leavening, and a maintenance-only cycle (riC 0) with cooling start. The four cycles have the following characteristics: cycle n°1 is carried out the same day (12 hrs); cycle n°2 is for the next day (24 hrs); cycle 3 for the second successive day (48 hrs); and cycle 4 for the third successive day after the (72 hrs).

To enter the recipes programming mode press key 4 until the letters **riC** appear on the temperature display and the numbers **01 ... 04** on the RH% display. Use keys 4 and 7 to select the recipe to be programmed, press key 3 to enter programming mode for the selected recipe. The 20 segments at the top of the unit should all be off: only one of the first four will remain on to remind you of the recipe you are programming. To program the data proceed as follows:

1. Use the (**▲**) or (**▼**) key to select the variable to be modified. After selecting the desired variable it will be possible to:
2. View the value on the respective sector of the display (5 or 17 page 11).
3. Modify the setting by pressing or maintaining the SET key and pressing the (**▲**) or (**▼**) key.

Exit programming mode [from the product ready day window (LI6)] by keeping key 4 pressed for 2 seconds; in any case the unit will exit programming mode if no keys are touched for 30 seconds.

CYCLE PROGRAMMING DATA:

DISPLAY TEMP.	DISPLAY RH%	DISPLAY TIME	Default recipe 1	Default recipe 2
AC1	Cooling temperature -20°C.....0°C.	Off	-7	-10
AC2	Off	Cooling time 00:00:00....29:59:00	04:00:00	05:00:00
Co1	Maintenance temperature -- --5°C.....15°C.	Off	-2	-4
Co2	Hr% Maintenance 50%....99.0%	Off	50	50
Li1	Final leavening temp. 10°C.....+45°C.	Off	27	30
Li2	Off	Leavening duration t1+t2+t3+t4+t5..09:59:00	04:00:00	05:00:00
Li3	Final leavening RH% 50%....99.9%	Off	80	85
Li4	Off	Product ready time 00:00....23:59:00	02:00:00	02:30:00
Li5	End-of-cycle settling 1=Yes 0=No	Off	0	0
Li6	Off	Product ready day 01:01:04....31:12:99 (read only)	/	/

N.B. the 00 cycle is dedicated to a cool-only cycle that consists of an initial cooling phase followed by a switch to maintenance for an indefinite period; the programmable data items for this recipe are therefore **AC1; AC2; Co1; Co2**.

Once programming has been completed you can start a cycle by pressing key 3 for a few seconds. The display asks which recipe is to be used (riC 00 ... riC 04). Select the desired recipe via the up/down keys: when key 3 is pressed again the product ready (oven-ready) time and day are displayed for 5 seconds. If the shown data is correct there is no need to carry out any further tasks and the controller makes subsequent checks and then starts the cycle. If, however, the data is incorrect stop the cycle by pressing key 3, enter the recipe, modify the incorrect data and restart the cycle.

The controller makes a quick calculation to see if the cycle duration time is compatible with the "product ready" time and day. If everything is compatible the cycle begins and the first segment lights up. If, instead, there are incompatibilities the controller goes to stand-by, the buzzer sounds and the **EP** message appears on the display to

indicate erroneous programming. To switch off the buzzer press key 7. The progress of the cycle is highlighted at the top of the unit as follows:

Phase 1: cooling n° 5 segments;

Phase 2 maintenance n° 5 segments;

Phase 3 leavening n° 6 segments;

Phase 4 settling (where enabled) n° 4 segments.

If a settling phase is enabled sector 19 will light up at the cycle **START** to remind the user that, when the product ready time is reached, the cycle will be completed by a settling phase. It goes off at the start of the settling phase (i.e. when segment n° 17 lights up).

While a complete cycle is being carried out the number of the recipe “**riC 01**” can be viewed on the RH% display and the baking day/time displayed alternately on the clock display (17) for a few seconds by pressing key 3 briefly. While a complete cycle is in progress you can view and modify the recipe in use by pressing key 4 for 2 seconds: you can vary temperature and humidity **but not the duration times of the different stages**.

At the end of the final leavening cycle (if settling is not enabled) the controller goes to stand by. The buzzer sounds and the segment bar flashes to indicate that the cycle is over. Buzzing/flashing stops automatically after 1 minute or when key 7 is pressed.

The user can vary temperature and humidity set-points alternately at any time during the active cycle (manual heat/cool cycles included) via key 6: note, however, that during a complete cycle variation of the set-point is relative to the phase in progress.

The first phase is known as cooling (cold is produced and “accumulated”). If the recipe has a cooling time of 0:00 the controller immediately goes to the maintenance phase at the start of the cycle.

There then follow: maintenance, intermediate leavening, final leavening and (where enabled) settling.

N.B. the end of the cycle (Li4 - product ready time) is defined by the end of the final leavening phase, not the settling cycle.

The cooling phase is characterised by:

- Temperature set-point
- Duration of the phase

The maintenance phase is characterised by:

- Temperature set-point
- Humidity set-point

The leavening phase is characterised by:

- Temperature set-point
- Humidity set-point
- Duration of the intermediate leavening phases via 2nd level parameters and overall leavening duration programmed by final user. N.B. overall leavening duration can never be less than the sum of the 5 parameter-programmed steps.

The settling phase is characterised by:

- Duration in hours (2nd level parameter)
- Temperature set-point (2nd level parameter)
- Humidity set-point (2nd level parameter)

If a phase has time 0, it is not executed and the controller goes to the next phase.

Phase times continue even in the event of an electrical power failure or controller stand-by.

When an automatic cycle is in progress it is possible to check the number of the cycle in use and the in-oven day / time by briefly pressing key 3 (CYCLE START); sector 17 of the display (DATE TIME) shows first day and then time.

The TeleWIN PRO supervision system allows the user to create a historical room temperature and humidity database via Personal Computer.

To connect the TeleWIN PRO system all you need to do is:

-Connect the two terminals 19-20 to the respective terminals 3 and 4 of the RS-485 interface (see TeleWIN PRO manual).

-Assign the PLUS 100 PAN system address via the configuration sequence by selecting the **Ad** label from the 2nd programming level (installer level) and following the normal address attribution criteria used for TeleWINPRO.

Temperature as detected by the controller can be displayed at the TeleWIN PRO address **Ad+1** by setting the module as TWMT (temperature acquisition module).

In this way the TeleWIN PRO supervision program can simultaneously display temperature and relative humidity as measured by the PLUS 100 PAN and build up a record of both parameters.

Example: if parameter **Ad** is set to **3**, relative humidity can be displayed on the TeleWIN by assigning the TWMUR module to address 3; temperature can be displayed by assigning address 4 (obtained by summing one to the parameter $Ad=3$) as the TWMT module.

N.B. The address $Ad+1$ can, in any case, be used by any device connectable to the TeleWIN (in place of PLUS 100 PAN temperature display) except for TWMT modules to which a different address must be assigned so as to avoid any conflict.

CHAPTER 7: TROUBLESHOOTING

7.1

ALARMS: DESCRIPTION AND PROCEDURES

ALARMS: DESCRIPTION AND PROCEDURES

In the event of any anomalies the PLUS 100 PAN system warns the operator by displaying alarm codes and sounding the warning buzzer inside the control panel. If an alarm is tripped the display will show one of the following messages:

ALARM CODE	POSSIBLE CAUSE	PROCEDURE TO BE FOLLOWED
E0	Temperature sensor not working properly (stops the system)	<ul style="list-style-type: none"> • Check the temperature sensor • If the problem persists contact the technical assistance service
E1	Humidity sensor not working properly (stops humidity control)	<ul style="list-style-type: none"> • Check the humidity sensor • If the problem persists contact the technical assistance service
E2	Evaporator sensor not working properly (defrostings scheduled)	<ul style="list-style-type: none"> • Check the evaporator sensor • If the problem persists contact the technical assistance service
E3	EEPROM ALARM EEPROM memory error detected. (all outputs deactivated)	<ul style="list-style-type: none"> • Switch off unit and switch back on • If the problem persists change the control board
E4	Software compatibility error	<ul style="list-style-type: none"> • Check for correct match between MASTER board and control panel board
E6	Flat battery	<ul style="list-style-type: none"> • Contact the technical assistance service to have the battery replaced
EC	Compressor safeguard (e.g. overheat or excess pressure). (Compressor and dehumidification output deactivated if parameter dEU = 0 or 1)	<ul style="list-style-type: none"> • Check compressor status • Check compressor absorption • If the problem persists contact the technical assistance service
En	No connection between control panel and control board	<ul style="list-style-type: none"> • Check connections between the two units • Check for presence of ferrite on sensors • If the problem persists contact the technical assistance service
EP	Erroneous recipe programming (goes to stand-by)	<ul style="list-style-type: none"> • Check recipe duration with product-ready time and day at the moment of cycle START.

EU	Humidifier alarm (relevant output does not deactivate)	<ul style="list-style-type: none"> • Check specific alarm type on humidifier control.
EF	Fan overheat safety device (relevant output not deactivated)	<ul style="list-style-type: none"> • Check fan absorption • If the problem persists contact the technical assistance service

TROUBLESHOOTING GUIDE

7.2

PROBLEM	PROBABLE CAUSE	PROCEDURE TO BE FOLLOWED
The Control Panel does not respond and the display is blank	Power supply fault (check connection lead to control board). Control board power supply not connected. Incorrect connection between Control Panel and Control Board (Panel power supply probably inverted with RS-485 signal)	* Check that power arrives at the Panel and/or Control Board terminals. Check connections between Control Panel and Control Board. If the problem persists contact the technical assistance service.
The Control Panel does not respond and the display reads En	Incorrect connection between Control Panel and Control Board. Connection between Control Panel and Control Board interrupted	Invert RS-485 signal lead connection. *Check connections for continuity.
The PLUS 100 PAN system generates false alarms	Sensor(s) connected incorrectly or faulty	Check all connections Check Control Board connection leads for continuity. If the problem persists contact the technical assistance service
The humidity sensor does not display the correct humidity value	Sensor is not connected properly. Correct type of humidity sensor not selected.	Check that sensor is working properly and that connection is correct.
The PLUS 100 PAN system does not respond to the parameters set on the configuration	Incorrect parameter settings	Check the system configuration settings.
The PLUS 100 PAN system does not dialogue with the TeleWIN PRO	Connection of PLUS 100 PAN system to the TeleWin module network has not been made correctly	• Check the connection to the TeleWin network. Check attributed address

ALLEGATI / APPENDICES

A.1

DICH. DI CONFORMITA' CE / EC DECL. OF CONFORMITY

COSTRUTTORE / MANUFACTURER

PEGO SRL Via Piacentina,6b 45030 Occhiobello (RO) - ITALY -

DENOMINAZIONE DEL PRODOTTO / NAME OF THE PRODUCT

MOD.: PLUS 100 PAN

IL PRODOTTO E' CONFORME ALLE SEGUENTI DIRETTIVE CE / THE PRODUCT CONFORMS WITH THE REQUIREMENTS OF THE FOLLOWING EUROPEAN DIRECTIVES:

- 2006/95/CE** Direttiva del Consiglio per l'unificazione delle normative dei Paesi CEE relativa al materiale elettrico destinato ad essere utilizzato entro certi limiti di tensione e successive modificazioni
- 2006/95/EC** EC Directive on unification of laws of the Member States relating to electrical equipment employed within certain voltage limits and subsequent amendments
- 89/336 CEE** Direttiva del Consiglio per l'unificazione delle normative dei Paesi CEE relativa alla compatibilità elettromagnetica e successive modificazioni
- 89/336 EEC** EC Directive on unification of the laws of the Member States relating to electro-magnetic compatibility and subsequent amendments
- 93/68 CEE** Direttiva del consiglio per la marcatura CE del materiale elettrico destinato ad essere utilizzato entro talunni limiti di tensione.
EC Directive on marking of electrical materials to be used within such voltage limits with the EC logo.


**LA CONFORMITA' PRESCRITTA DALLE DIRETTIVE E' GARANTITA DALL' ADEMPIMENTO A TUTTI GLI EFFETTI DELLE SEGUENTI NORME:
CONFORMITY WITH THE REQUIREMENTS OF THIS DIRECTIVE IS TESTIFIED BY COMPLETE ADHERENCE TO THE FOLLOWING STANDARDS:**

NORME ARMONIZZATE / HARMONIZED EUROPEAN STANDARDS

EN 61000-6-1 EN 61000-6-3 EN 60335 – 1

PLUS100 PAN CONNECTIONS DIAGRAM

A.2

**Power section**

45-46 Power supply 230 V AC 50 Hz

Inputs section

3-4 Evaporator sensor NTC 10K

5-6 Humidity sensor 4..20 mA

(5=V+ 6=Y)

7-8 Ambient sensor NTC 10K

9-15 Fan overheat safety device

9-16 Humidifier alarm

9-17 Door switch

9-18 Compressor safety device

Outputs section (no-voltage contacts)

25-26 Alarm

27-28 Defrosting

29-30 Dehumidification / air changeover

31-32 Stand-by

33-34 Humidification

35-36 Room light

37-38 Evap. fans low speed (*)

39-40 Evap. fans high speed (*)

41-42 Heat

43-44 Cold

TeleWIN section

19-20 RS485 for TeleWIN

(*)High speed
Low speedterminals 39-40 closed, terminals 37-38 open
terminals 39-40 open, terminals 37-38 closed.



PEGO s.r.l. Via Piacentina, 6/b 45030 Occhiobello ROVIGO – ITALY
Tel. +39 0425 762906 Fax +39 0425 762905
e.mail: info@pego.it – www.pego.it